

TOYOTA Land Cruiser 75 Series (Dual Battery and ARB Compressor) Direction-Plus[™] Post-Filter Kit Installation Guide


This document is to be used as a guide for the installation of **the Direction-Plus™ Fuel Manager™ Post-filter Kit** (**PF625DPK**) to a Toyota 75 series. It is recommended that the installation of the product be carried out by a competent qualified mechanic.

Important before starting

- Ensure the engine bay is clean and free from contaminants
- The fuel manager filter head has direction arrows indicating the direction of flow
- You have the correct tools to complete the fitment
- Read the instructions in full and familiarize yourself with the installation, before commencing any work

Kit contents

1x m8 1.25 x 40 z ps scr 1x 2 bolts 2 nuts 4 washers 1x 8mm x 17mm zinc 1x bolt - 6x25mm zinc 1x bracket - I/c 70 ser suits arb compress 2x dfl12 - fuel line rubber (12mm) 2x dp733-04 - npt plug 1x fm engine bay label 1x fm100 5 micron filter assy 2x fmc12 - clamp 12mm 1x loctite 567 thread sealant - 6ml 1x nut - nyloc 6mm 1x nyloc nut m8 2x push on straight - 12mm 1x washer - 6mm 1x windscreen label




Post-filter mounting location

*Kit contents are subject to change based on component availability and/or refinement



Fuel Manager Post-Filter Normal Flow Header Connection



Ports 2 and 3 = INLET Ports 1 and 4 = OUTLET



Installation Guide

- 1. On non-airbag model Land Cruiser, the small fuse panel will need to be relocated to the front of the battery tray support using the supplied 6mm nut and bolt.
- 2. Remove the two (2) 12mm bolts from the radiator support.
- 3. Place the supplied 8mm washer on to the radiator mounting stud. PLEASE NOTE the 8mm nut on the radiator support stud does NOT need to be removed.
- 4. Place the supplied Direction Plus mounting bracket on the radiator support stud and secure with supplied 8mm nut. Reuse and refit the two (2) 12mm bolts into the radiator support.
- 5. Attach the Direction Plus Post-Filter assembly to the bracket using the supplied 10mm bolts, washers and nuts.
- 6. Install the NPT adapters into the Post-filter assembly using the supplied LOCTITE thread sealant.
- 7. Install the NPT plugs into the two remaining ports using the supplied LOCTITE thread sealant
- 8. Lubricate the barbed end of one (1) of the push-lock fittings and the inside portion of the hose to be fitted with a push-lock fitting with diesel fuel or WD40.
- 9. Insert the barbed end of one (1) of the push-lock fittings into the pre-lubricated end of the hose. Ensuring that the hose is firmly stopped against the inside of the bell cover.
- 10. Connect the assembled hose to the inlet of the Post-filter assembly and route the hose around to the outlet of the factory fuel filter
- 11. Cut this hose to length and connect it to the outlet pipe of the factory fuel filter, secure with a supplied hose clamp
- 12. With the remaining supplied fuel hose lubricate the inside portion of the hose to be fitted with a push-lock fitting with diesel fuel or WD40.
- 13. Insert the barbed end of one (1) of the push-lock fittings into the pre-lubricated end of the hose. Ensuring that the hose is firmly stopped against the inside of the bell cover.
- 14. Connect the just assembled fuel hose to the outlet of the Post-filter assembly and route to the inlet of the common rail supply pump and secure with a hose clamp
- 15. Ensure all fuel lines are suitably secured.
- 16. Using the supplied nylon cable ties, secure any loose hose to prevent it from rubbing against any other components.
- 17. Prime the system using the hand primer on the factory filter. When the primer goes firm, the engine is ready to start.
- 18. Start and run the engine whilst checking ALL connections for leaks.

END OF GUIDE